

DESCALER

DIMENSIONS

Height:	108mm
Diameter:	57mm
Circumference	12.7mm



The Ecocamel descaler uses magnetic fields to change the polarity of compounds in the limescale and stop them sticking to metal surfaces like pipes, immersion heaters and the insides of kettles. This prevents limescale from building up and the magnetic action keeps on working every day to remove any existing limescale as well.

Remove and Prevent Limescale Build-up



Fitting Information

Simply take it out of the box, slide it apart, put one half at the back of your mains inlet pipe and slide the top half back onto it. And then just leave it to do its work. No screws, no electricity, just simple, energy efficient magnetism.

There is no maintenance just fit and forget.

* To fit the descaler, your main inlet pipe would need to be an inch minimum away from the wall. The descaler slides into place so it can be fitted in a confined space. You would, however, need about four or five inches of free pipe above or below where you intend to place it, in order to slide the two halves together.

** NB. Do not handle the magnets if your are on a heart pacemaker or similar as the magnets are very powerful. If you wear a quartz watch or have credit cards nearby remove them before handling the magnets as the magnets will stop your watch and wipe your credit cards clean.

CONTACT US

Ecocamel Ltd, Dephna House, 24-26 Arcadia Avenue, London, N3 2JU. United Kingdom.

Tel +44 (0)20 8211 3666 Fax +44 (0)87 0762 0012 Email customerservices@ecocamel.com Web www.ecocamel.com

Due to constant product improvement, we reserve the right to change product specification at any time without notice.